



(D) Videounterstützte Montageanleitung

(TR) Video destekli kurulum talimatları

(RU) инструкция по монтажу с помощью видеосигнала

(RO) Instrucțiuni de instalare acceptate video

(GB) Video-assisted assembly instructions

(IT) Istruzioni di montaggio video-assistite

(CZ) Instalační pokyny podporované videem



(PL) Instrukcje montażu wspomagane sygnałem wizyjnym

(FR) Instructions de montage assistées par vidéo

(NL) Video-ondersteunde montage-instructies

(HU) Video-támogatott telepítési utasítások










(SK) Inštaláčn  pokyny podporované videom



REPC-Nr.:

0560_80 Esstisch


Service • Assistenza • Dienstverlening • Serwis
Servis • Szerviz • Сервисная служба



Das Ersatzteil-Anforderungsformular finden Sie auf <https://www.maeusbacher.de/ersatzteile/>

Beutel 1/4

1-10		1-90		1-172		1-174	
4x	6,3x50	8x	3,5x20	28x	4,5x40	4x	4,5x50
2-20		2-90		5-130		5-190	
8x		4x	6x30	1x	LEIM	8x	
1-355		2-10					
4x	M 6	8x					



Beutel 2/4


1-300-12		2-107		5-20	
4x	M 6x65	8x	8x70	8x	

Beutel 3/4


1-122		2-174	
8x	4x13	4x	





Beutel 4/4

1-30		2-179	
4x	3x16	4x	





Colli 1/1






5








1-30		1-355		2-179		5-130		7
4x	3x16	4x	M 6	4x		1x		





6


5-20	
8x	







9


1-90	
8x	3,5x20
2-107	
8x	8x70








10



1-300-12	
4x	M 6x65







11

2-90	
4x	6x30



12

1-122		2-174	
8x	4x13	4x	

