





TRENTINO


Manual




52404 Dessoir 240x42x75 cm




52405 Dessoir 210x42x75 cm




52401 Lowboard 270x42x45/56 cm




52400 Lowboard 240x42x45/56 cm




52399 Lowboard 210x42x45/56 cm




52398 Lowboard 180x42x45/56 cm









52407 Dresseur 153x42x132 cm





52406 Storage Chest 95x42x190 cm






52402 Wall Unit






TOOL(S) NEEDED (not included)




ELEMENTS


ITEM(S)




52404 DRESSOIR 240x42x75 cm



52405 DRESSOIR 210x42x75 cm



52407 DRESSSETTE 153x42x132 cm




52406 STORAGE CHEST 95x42x190 cm



HARDWARE (included)

ID	Hardware	52404	52405	52407	52406
		DRESSOIR 240 cm	DRESSOIR 210 cm	DRESSSETTE 153 cm	STORAGE CHEST 95 cm
B	 Bolt M6x25 mm	12	12	12	8
D	 Washer	12	12	12	8
E	 Allen key with ball end	1	1	1	1
I	 Leg	2	2	2	2
J	 Central leg	1	1	1	0



1





2




3



4




5




ELEMENTS

ITEM(S)


Option: with plinth




52401 Lowboard 270x42x45/56 cm



52400 Lowboard 240x42x45/56 cm





52399 Lowboard 210x42x45/56 cm





52398 Lowboard 180x42x45/56 cm

1




2




ELEMENTS

ITEM(S)


Option: with legs




52401 Lowboard 270x42x45/56 cm



52400 Lowboard 240x42x45/56 cm




52399 Lowboard 210x42x45/56 cm




52398 Lowboard 180x42x45/56 cm


HARDWARE (included)

ID	Hardware	52401	52400	52399	52398
		Lowboard 270 cm	Lowboard 240 cm	Lowboard 210 cm	Lowboard 180 cm
B	 Bolt M6x25 mm	12	12	12	12
D	 Washer	12	12	12	12
E	 Allen key with ball end	1	1	1	1
I	 Leg	2	2	2	2
J	 Central leg	1	1	1	1


① Please remove first the plinth.




②




③





4




5



7




8




ELEMENTS

ITEM(S)


Option: hang to the wall




52401 Lowboard 270x42x45/56 cm



52400 Lowboard 240x42x45/56 cm




52399 Lowboard 210x42x45/56 cm




52398 Lowboard 180x42x45/56 cm


① Please remove first the plinth.






②



③







ASSEMBLY SET SAFETY WARNING


GB: We **STRONGLY** recommend you to secure the furniture to the wall.
 NL: Wij adviseren u **ZEER STERK** om uw meubel tegen de muur te bevestigen.
 FR: Nous vous conseillons **FORTEMENT** de fixer votre meuble au mur.
 DE: Wir empfehlen Ihnen **DRINGEND** Ihr Möbel an der Wand zu befestigen.

GB: Buy the correct screw and plug suitable for the wall.
 NL: Koop de juiste schroef en plug die geschikt is voor de betreffende muur.
 FR: Veillez à acheter les vis et chevilles correspondant à votre type de mur.
 DE: Kaufen Sie bitte richtige Dübel für Ihre Wand und dazu passende Schrauben.


Dimensions for wall assemble




ITEM(S)




52404 DRESSOIR 240x42x75 cm



52405 DRESSOIR 210x42x75 cm



52407 DRESSLETTE 153x42x132 cm





52406 STORAGE CHEST 95x42x190 cm



HARDWARE (included)

ID	Hardware	52404	52405	52407	52406
		DRESSOIR 240 cm	DRESSOIR 210 cm	DRESSLETTE 153 cm	STORAGE CHEST 95 cm
F	 Shelf support	4	4	4	8
G	 Glass shelf	1	1	1	2


1






2






3






ITEM(S)






52401 Lowboard 270x42x45/56 cm



52400 Lowboard 240x42x45/56 cm



52399 Lowboard 210x42x45/56 cm




52398 Lowboard 180x42x45/56 cm

HARDWARE (included)


ID	Hardware	52401	52400	52399	52398
		Lowboard 270 cm	Lowboard 240 cm	Lowboard 210 cm	Lowboard 180 cm
H	 Wire cover	1	1	1	1

Cable manager cover option:


1) Please apply first masking tape on the location indicated below (to avoid damages on the top)




52398 Lowboard 180 cm



52399 Lowboard 210 cm




52400 Lowboard 240 cm




52401 Lowboard 270 cm


2) Mark exactly the position where to drill, on the location indicated below:




52398 Lowboard 180 cm



52399 Lowboard 210 cm




52400 Lowboard 240 cm







52401 Lowboard 270 cm

3) Drill the hole with \varnothing 50 mm tool (tools are not included),




4) Remove the masking tape and remove dust

5) insert the cable management cover (F)




ITEM(S)



52402 Wall Unit

ITEM A		QTY 1
Support vertical		



ITEM B		QTY 1
Support horizontal		











ASSEMBLY SET SAFETY WARNING

GB: We **STRONGLY** recommend you to secure the furniture to the wall.
 NL: Wij adviseren u **ZEER STERK** om uw meubel tegen de muur te bevestigen.
 FR: Nous vous conseillons **FORTEMENT** de fixer votre meuble au mur.
 DE: Wir empfehlen Ihnen **DRINGEND** Ihr Möbel an der Wand zu befestigen.

GB: Buy the correct screw and plug suitable for the wall.
 NL: Koop de juiste schroef en plug die geschikt is voor de betreffende muur.
 FR: Veillez à acheter les vis et chevilles correspondant à votre type de mur.
 DE: Kaufen Sie bitte richtige Dübel für Ihre Wand und dazu passende Schrauben.




The Wall Unit can be fixed against the wall on all 4 sides (horizontal or vertical)







HOW TO FIX HIGH ITEMS AGAINST THE WALL



52407 Dressette 153x42x132 cm







52406 Storage Chest 95x42x190 cm



ASSEMBLY SET SAFETY WARNING

GB: We **STRONGLY** recommend you to secure the furniture to the wall.
 NL: Wij adviseren u **ZEER STERK** om uw meubel tegen de muur te bevestigen.
 FR: Nous vous conseillons **FORTEMENT** de fixer votre meuble au mur.
 DE: Wir empfehlen Ihnen **DRINGEND** Ihr Möbel an der Wand zu befestigen.


GB: Buy the correct screw and plug suitable for the wall.
 NL: Koop de juiste schroef en plug die geschikt is voor de betreffende muur.
 FR: Veillez à acheter les vis et chevilles correspondant à votre type de mur.
 DE: Kaufen Sie bitte richtige Dübel für Ihre Wand und dazu passende Schrauben.






HOW TO ADJUST / REMOVE DOOR(S)


Tools




Installation




Removal




Height adjustment



Overlay adjustment




Depth adjustment






HOW TO ADJUST / REMOVE / INSERT DRAWER(S)


Adjust height of drawer by turning the wheels on each side (individually)




Remove drawer by holding the handle



Insert drawer by sliding at a slight angle




Secure drawer by pushing it inward





HOW TO CONNECT TRANSFORMER TO LED





READY! ENJOY YOUR NEW FURNITURE AND
PLEASE READ OUR PASSPORT FOR
MAINTAINING YOUR FURNITURE PROPERLY



FR

Pensez à
donner ou recycler.



Association

ou



Magasin

ou



Déchèterie

<https://quefairedemesdechets.fr>